





# eDIP 240-7 (touchscreen version) connection circuit 18.8.2006




## DIP switch settings:



**Normal mode:**  
Controller and display are connected via I<sup>2</sup>C.




**Programming mode:**  
Display is connected to PC via RS232.



**If you have programmed an endless loop in the Power-On, Reset or Watchdog macro, the display can't be reprogrammed anymore.**  
Follow those steps to upload new macros:

1. Power off, set the switches as shown:



2. Power on, set the switches as shown, upload new macros.

